

**Installation Instructions - JLT Cold Air Intake**  
 2015-18 Hellcat Charger/Challenger #CAI-HC-15

Thank you for purchasing our product. We hope you are satisfied with the look and performance. If you have any questions, please feel free to call us first before going to the internet. Take your time and it will be a smooth install.

Please review complete instructions prior to installing.

We find it easiest to install the kit as a complete assembly; however, it can be done one piece at a time. Here is a walk through:

1 Verify you have all of the following parts included in the kit:  
 (1) JLT Plastic Intake tube (1) 4.5"-4" Silicone Reducer, (1) 5"x7" Air Filter, (1) JLT Heat Shield, (1) 64 Clamp, (1) 72 Clamp, (1) Rubber grommet, (1) Charger Rain Shield, (1) Challenger Rain Shield, (1) IAT Adapter for use on 2017-18 models, (1) MAF Adapter for use on 2015-16 models, (1) Adapter gasket, (6) M4x10 machine screws, (1) Foam ram air gasket (1) Alcohol pad

2 Gather all of the following tools needed for the installation:  
 5/16 Nut Driver, Phillips screwdriver, T20 Torx bit and 10mm wrench


3 Remove the stock intake from the throttle body to the airbox.  
 5/16 or 8mm - Remove the bolt holding the box in the car and the 3 bolts holding the top to the box.  
 Loosen the clamp at the throttle body, unplug IAT/MAF sensor and PCV connections.



4 **CHARGER:** Unclip(squeeze) the 4 retaining clips in the air box holding the Fresh Air inlet to the box and remove the lower air box.  
**CHALLENGER:** Remove the radiator cover panel(cover simply pulls up) above the headlight. Remove the lower air box and disconnect the Fresh Air inlet from the box.



- 5 Remove the rubber location grommet from the stock air box and install into the hole in the apron.



- 6 Lower JLT Air Box into position.  
TIP: Remove the 10mm bolts holding the coolant tank and move back for more room.  
Push JLT shield into the location grommet, use the factory bolt and secure to the car.




- 7 **CHALLENGER:** route the factory inlet tube through the heat shield, onto the headlight.  
Use the supplied FOAM GASKET to seal the Fresh Air Inlet tube to the heat shield.  
**\*\* Clean surface with supplied alcohol pad first!!\*\***




8 Remove from factory intake: MAF or IAT sensor(Twist to unlock), PCV connection  
Assemble JLT tube: Install reducer, filter, PCV connection and correct adapter on the tube

9 2015-16 will use the MAF slot adapter WITH SUPPLIED MAF SCREWS!!!  
2017-18 will use the IAT adapter  
Use the supplied screws and gasket and mount the needed adapter to the JLT tube.  
NOTE: MAF adapter has a DIMPLE that goes toward the throttle body



10 Slide the tube onto the throttle body and rotate down into the heat shield.

11 Route MAF or IAT plug through the hole in the heat shield and plug in. Use the supplied grommet in the hole to protect the wires.



12 RAIN SHIELDS:  
Remove the protective film from the shield. Remove both 10mm bolts holding the hood vent in and sandwich the shield BETWEEN the hood and grille and reinstall the bolts.



13

### CHALLENGER HOOD ADJUSTMENT:

Because the box seals to the hood you will need to adjust the PASSENGER side hood bumper UP a turn or 2 to bring the driver side of the hood DOWN. Do a little at a time until it is even with the fenders on both sides.



Adjust passenger side up

2018: Twist factory hard line and fitting into this position to fit into grommet on the JLT tube.



**Oil Filter:** The frequency you should clean your filter will depend on your driving conditions. It is recommended to check your filter at every oil change or 3,000 miles. If there is a build up of dirt as thick as the wire mesh, then it's time to clean your filter. As dirt builds up on your filter, the restriction of the airflow also increases. More frequent cleanings will improve your fuel economy and your vehicle's performance. To properly clean your oil filter, we recommend the S&B Precision Cleaning & Oiling Kit (located in the Parts Sold Separately Section of our website, [www.JLTtruecoldair.com](http://www.JLTtruecoldair.com)).

Thanks for the business. If you have any questions, please e-mail [info@JLTtruecoldair.com](mailto:info@JLTtruecoldair.com) or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

**Warranty:** JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

**Disclaimer:** JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

**Custom Paint Disclaimer:** All custom paint jobs are done by JLT Performance Inc. Every job is different and done by hand. By ordering a custom paint job, you accept this fact and cannot hold JLT Performance liable for the end result not being exactly what you had in your mind.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit [www.JLTtruecoldair.com](http://www.JLTtruecoldair.com) for complete return policy.